



Sticky Trigger SCP-1


This document applies to all SCP-1 1.1.

The trigger of the SCP-1, particularly the 1.1 version, can become sticky, at times. This means that the trigger may not properly return to its 'zero' rest position, or do it more slowly than expected. This condition can be easily cured.


Take a can of WD40 or equivalent with the 'straw' - like the one in the picture:



Spray a little between the PCB and the trigger assembly:



Spray a little in the small hole on top of the screw which keeps the trigger in place:



Keep moving the trigger until you get a perfectly smooth movement.

This is essential to get a properly working SCP-1